

Main Office
415 Route 10 East
Randolph, NJ 07869
Phone: (800) 831-5771
Fax: (973) 537-1420

Engineering Group
101 N. Plains Industrial Rd
Wallingford, CT 06492
Phone: (203) 265 - 7022
Fax: (203) 265 - 3588

www.visitorwatch.com
info@visitorwatch.com



Zebra Autosense Procedure

Autosense Procedure, Configuration Label and Dump Mode:

Models: Orion (2442, 2443 and 2543), Transport (P-2242), Xport (P-2222), LP/TLP Strata (2684), LP/TLP-2722, 2742, 3742, LP/TLP-2824, LP/TLP 2844 and TLP-3842

1. Turn off printer and have media loaded (on older Transports, with no ON/OFF switch, remove battery).
2. Hold feed button down, and turn printer back on (on older Transports, re-insert battery) while holding down the feed button.
3. When the light starts flashing, release the feed button.
4. Printer light will turn green and advance a few blanks.
5. After printer stops advancing and prints the [internal information](https://support.zebra.com/cpws/docs/eltron/epl_config.htm) (https://support.zebra.com/cpws/docs/eltron/epl_config.htm), press the feed button one time.
6. You will get another label with the "Out of Dump" message on it.

Printer is now ready for use.